



## WAVE OnCloud Gateway Getting Started Guide

### Setting up WAVE OnCloud Gateway

After you have unpackaged the machine:

1. Plug LAN cable into back of machine- IMPORTANT:
2. Power On Machine


**You'll need to connect to gateway device to ensure it can connect to the internet!**


Use the machines WIFI:

WIFI SSID: %WOCG-SERVICE TAG%

WIFI Password: MotoGateway

Example:





Once connected to devices WIFI, open a browser  
Go to:

<http://192.168.173.1/>

This is the home page for the device.

A screenshot of the WAVE OnCloud Gateway Device home page. At the top center is the Motorola logo followed by the text "WAVE OnCloud Gateway Device". Below this is a section titled "Device Code" with a light blue bar containing the code "FDCZGNRY". The page is divided into two main sections: "Network Health Status" and "System Information".  
**Network Health Status**

Description	Status	Last Successful
Internet Accessible	✓	02/01/2017 11:56:36
Local Network Accessible	✓	02/01/2017 11:56:35
Network Card Configuration	✓	02/01/2017 11:56:35

  
**System Information**

Software	
Software Versions	
- WAVE Radio Gateway	5.12.0.66475
- WAVE On Cloud Gateway	Software Not Found
Service	
- MOTOTRBO Network Interface	5.12.0.66475
Hardware	
Machine Name	WOCG00005
Service Tag Id	WOCG00005
WiFi Hotspot Name	WOCG00005

© 2017 - WAVE OnCloud Gateway Device

If the homepage looks like this- you're all set!

IMPORTANT: Write the Device Code here:

Device CODE: \_\_\_\_\_  
(you will need this to associate with radio system)

If you see a **red X** thru network card configuration, click the link- Network Card Configuration. By default it is set to use DHCP. You can use a specific IP address--if they is how your network is configured.

## Change IP Address

Static IP Address  DHCP IP Address

### DHCP IP Address Info

---

**IP Address :** 10.100.120.101

**Subnet Mask :** 255.255.255.0

**Default Gateway :** 10.100.120.1

**Primary Dns :** 10.100.30.6

**Secondary Dns :** 10.100.10.6

Save

Cancel

---

## Change IP Address

Static IP Address  DHCP IP Address

### Static Ip Address Info

---

#### IP Address

IP Address of the Network Card

(10.100.120.101)

#### Subnet Mask

Subnet Mask of the Network Card

(255.255.255.0)

#### Default Gateway

Default Gateway's IP Address

(10.100.120.1)

#### Primary Dns

Primary DNS's IP Address

(10.100.30.6)

#### Secondary Dns

Secondary DNS's IP Address, if needed

(10.100.10.6)

Save

Cancel

Enter your network values and click SAVE.

## Assistance

For technical feedback and help:

- For non-urgent help:
  - [WOCBETA@motorolasolutions.com](mailto:WOCBETA@motorolasolutions.com)
- For urgent help:
  - You can call **800 927 2744** option 3,6, and 2 which will route you to the WAVE support team.

To discuss product roadmap and business matters:

- [adil.berdai@motorolasolutions.com](mailto:adil.berdai@motorolasolutions.com) or
- [eric.brown@motorolasolutions.com](mailto:eric.brown@motorolasolutions.com)